



### Assembly instructions

1. Fasten adaptors to soft close mechanism with M4 screw supplied
2. Fit assembled soft close mechanism to top corner of door panel (instead of top guide) on the side the door will close against the jamb. Fix off both adaptors with 2 x 2 RM213 tek screws.
3. Striker is installed on site once top track and door panel are installed  
Important door be adjusted to suit opening before the next step. Also don't adjust door up to high so as to not allow enough clearance for striker.  
there is enough clearance for striker
4. To get striker in correct position, move door panel 300mm away from jamb, put striker into the head track (friction will hold in place) and with the striker pin towards the middle of the door opening. Adjust the striker down if needed to ensure the pin will catch on the soft close mechanism. Push panel to the until it catches and bottoms out then move teh door to closed position. This will move the striker to its home position. Push door out of the way so striker can be fixed off with 2 x RM213 tek screws..